

SCANGRIP UV MOUNTING BRACKET

Reference: 03.5915



SCANGRIP UV MOUNTING BRACKET

To attach UV-EXTREME or UV-EXTREME PLUS to the underside of the WHEELCHAIR, this additional MOUNTING BRACKET is required as an accessory.