



PRAMAC AUTOMATIC INTERVENTION PANEL AMF

Reference: PY000A0000S

PRAMAC AMF AUTOMATIC INTERVENTION PANEL

Pramac AMF automatic Panel with quick coupling connector for simple and quick connection to the group.
The Pramac AMF monitors the public network and, in the event of a voltage failure, starts the genset and feeds the use, when the mains returns, it opens the generator contactor, switches the load to the mains and commands the engine to stop.

Thanks to the Pramac AMF automatic Panel, you will no longer have to worry about blackouts because if the current goes out, this switchboard is able to automatically start the generator and will allow you to continue your business without losing your work data.

Equipment

- Control and command unit (DGT)
- Phase sensor
- Switching with interlock
- Charging maintenance battery
- Acoustic alarm
- 8m auxiliary connection cable
- external start stop command
- Emergency stop button

Instrumentation (DGT)

- Mains voltage
- Generator voltage
- Frequency meter
- Hour-counter

Alarms and Protections

- Generator voltage out of limits
- Battery charge fault
- Low oil level
- Starting failure
- External stop

Are you looking for a product with different characteristics? [HERE](#) you can find the area dedicated to Pramac or other specialized brands.

The image is purely indicative.

Technical Sheet

Product type

Switching Frame