

SINCRO RD2 DIGITAL AVR FOR IB MODELS

Reference: AVR DIGITALE IB



RD2 Digital AVR (mounted on the alternator instead of the analogic AVR) for IB models.